CS3310 installation guide

1. Package includes:

- 1. Main board x 1
- 2. IR receiver and display board x 1
- 3. Remote handset
- 4. Screw pack x1

2. Installation

- 1. Fix the main control board on the chassis.
- 2. solder the signal source from the chassis to the CS3310 main board related area, solder the main board output point to the preamplifier PCB input point.
- 3. Connect the Display board to the main board with the ribbon cable provided. Cable with Red marked face the main board's volume side.
- 4. Solder the transformer to the main board, 2 x ACO-12V, 1 x ACO-9V or 3 x ACO-12AC
- 5. connect the CS3310 with AC, input sources should be "2", and the volume should be -80dB. You can control the volume and input sources from the front panel or the remote handset.

